

























## Price List

### Compatibility - Flush plates and buttons

Flush plates				UP320	UP200	AP123
<b>Sigma10</b> 	<b>Rumba</b> 	<b>Tango</b> 	<b>Mambo</b> 	✓		
<b>Sigma20</b> 	<b>Sigma50</b> 	<b>Samba</b> 	<b>Bolero</b> 	✓		
<b>HyTronic infra-red</b> 				✓		
<b>Large Access Cover Plate</b> 				✓		
<b>Kappa20</b> 	<b>Kappa50</b> 	<b>Artline</b> 			✓	
<b>Small Access Cover Plate</b> 					✓	
<b>HyTouch single flush buttons</b>						
<b>Short wall palm</b> 115.114.xx.1 241.199.xx.1 	<b>Short wall finger</b> 115.947.xx.1 241.198.xx.1 	<b>Short wall palm</b> 115.949.21.1 241.282.21.1 		115.114.xx.1 115.947.xx.1 115.949.21.1 115.943.21.1 115.941.xx.1	115.114.xx.1 115.947.xx.1 115.949.21.1 115.943.21.1 115.941.xx.1 111.942.xx.1	241.199.xx.1 241.198.xx.1 241.282.21.1 241.144.00.1 115.941.xx.1
<b>Long wall finger</b> 241.144.00.1 	<b>Long wall finger</b> 115.943.21.1 	<b>Palm push</b> 115.941.xx.1 				
<b>HyTouch dual flush buttons</b>						
<b>Hand push</b> 115.942.xx.1 	<b>Finger push</b> 115.999.21.1 	<b>Finger push</b> 115.070.21.x 		115.942.xx.1	115.070.21.x 115.999.21.1	
<b>HyTronic infra-red buttons</b>						
<b>Sensor flush</b> 				115.857.xx.1		